

# Components of a Tide Gauge Record and General Principles of Quality Control

St Lucia, 17<sup>th</sup>-21<sup>st</sup> October 2016

Angela Hibbert, Phil Woodworth  
National Oceanography Centre, Liverpool



National  
Oceanography Centre  
NATURAL ENVIRONMENT RESEARCH COUNCIL

[noc.ac.uk](http://noc.ac.uk)

**NERC** SCIENCE OF THE  
ENVIRONMENT

# Sea Level Variability


Sea levels vary on different time scales and for different reasons:



- Tsunamis (10s of minutes to an hour)
  - Seiches (minutes to hours)
  - Tides (diurnal, semi-diurnal, mixed)
  - Storm surges (few days)
  - Seasonal cycle (annual, semiannual)
  - Mean sea level changes (months – millennia)
- } 1 min sampling or less
- } 5 to 15 min sampling

Sea level is measured by a tide gauge which take either spot-measurements at regular time intervals, or averages (called integrations) over the time intervals.

# Tides


Periodic movements which are directly related in amplitude and phase to variations of **the tidal gravitational potential** on the surface of the earth, caused by regular movements of **the Moon-Earth and Earth-Sun systems**.





- Synodic or lunar month - 29.53 days
- Lunar orbit – 27.55 days and 8.85y cycle
- Lunar declination – 27.21 day and 18.61 year cycles


Different types of tide:  
**Diurnal**




**Mixed**



**Semi-diurnal**



**Semi-diurnal**



**Shallow sea distortions**




5 10 15 20 25 30


March 2043



$M_2$



$K_1$



# Non-Tidal Variability

Non-tidal components might include:

- **Storm surges** caused by changes in air pressure and winds
- **Seiches** due to resonant behaviour of harbours and bays
- **Tsunamis** caused by earthquakes, submarine landslides etc
- **Seasonal** changes due to changes in water density
- **Long-term trends** due to climate change





# Storm surges

Storm surges occur due to a combination of:

1. Low air pressure (1 mbar reduction raises sea level by 1 cm, known as the **Inverse Barometer Effect**)
2. **Wind stress** in shallow water, the surge being proportional to Stress/Depth




# North Sea storm surge of 1953



Sea Palling, Norfolk (1 Feb 1953)




Thames Barrier





## New Orleans after the Katrina storm surge

## Grand Isle, Louisiana



A tide gauge near New Orleans during Hurricane Katrina

# Seiches

- Seiches are due to resonance in bays, harbours etc. with fundamental frequency that is proportional to  $1/\sqrt{\text{depth}}$
- Sometimes they can be many decimetres in amplitude and have associated currents that can damage shipping e.g. in the Mediterranean (Rissaga)
- In practice, they occur in all sea level records and can be readily identified given high frequency sampling.




# Seiches can be generated by:

- Rapid meteorological changes
- Tides
- Internal tides
- Other ocean processes
- Earthquakes
- Landslides
- Tsunamis

and any other disturbance that initiates resonance



# Seiches for 2 days at Trincomalee Bay, east coast of Sri Lanka




# Tsunamis

- Caused by undersea earthquakes, submarine landslides, terrestrial landslides, volcanic eruptions, asteroid and comet impacts, man-made explosions.
- A big subject with lots of literature. Stuart Weinstein will discuss in more detail in his talk.









## 26 December 2004 Sumatra tsunami



### Tropical Indian Ocean



### South Atlantic




The 26 December 2004 tsunami was observed in tide gauge records on many coastlines

### Indian Ocean gauges


# Long Term Changes

- Long term changes e.g. IPCC concluded that there has been a global rise of approximately 10-20 cm during the past 100 years



# Tidal Analysis and Quality Control


Some of the variations we have seen are so extreme that they are obviously identifiable in raw tide gauge records:



However, some variations can be masked by tides. Therefore, tidal and non-tidal components of a sea level record are often separated, making the non-tidal variations much clearer.

# How does a tidal analysis work?

The tide is parameterised in terms of harmonics with periods specified by the orbits of the Moon and Sun but with unknown amplitudes and phase i.e.




$$Tide = Z_0 + \sum_{j=1}^N H_j f_j \cos[\sigma_j t - g_j + (V_j + u_j)]$$

The unknown parameters are  $Z_0$  and the  $(H_j, g_j)$ .


The fitting is adjusted so that the sum of the squares of the difference between the observed and computed tidal levels is minimized. The residuals to the fit are considered to be the 'non-tidal' terms.

# An example from Port Stanley Nov-Dec 2004


Measured



Tide



# An example – Port Stanley, Falkland Islands




Non-tidal record shows:

1. No big storm surges (Southern Hemisphere summer)
2. A lot of high-frequency noise of a few cm due to harbour seiches
3. On 27 December arrival of the Sumatra tsunami (15 cm or so)

→ None of this is evident from looking at the total measured record.

# Port Stanley



December 2004





## Uses of tidal analysis

1. The separation of the sea level record into tidal and non-tidal components is needed to produce tide tables or tidal predictions
2. The non-tidal signals (seiches, tsunamis) become clearly identified
3. Tidal analysis also enables errors in the sea level time series to be identified → highest-quality data for subsequent analysis



# Principles Of Quality Control

*“To ensure the data consistency within a single data set and within a collection of data sets and to ensure that the quality and errors of the data are apparent to the user who has sufficient information to assess its suitability for a task.” (Unesco, 1993)*



# GLOBAL SEA LEVEL OBSERVING SYSTEM (GLOSS)



## MANUAL ON QUALITY CONTROL OF SEA LEVEL OBSERVATIONS

Version 1.0




**National  
Oceanography Centre**  
NATURAL ENVIRONMENT RESEARCH COUNCIL

[noc.ac.uk](http://noc.ac.uk)

**NERC** SCIENCE OF THE  
ENVIRONMENT

# Principles Of Quality Control

Scheme of principal data available from a tide gauge station and the processing normally applied to sea level data. Most present day sensors will provide digital output.





# Principles Of Quality Control


It will be immediately clear (especially with some experience) by looking at the residuals if there is:

- A spike or jump in the data due to instrumental faults  
These can be evaluated by 'buddy checking' and flagged using GLOSS QC standard flags
- Missing data (small gaps can be interpolated)
- Reference level changes
- A timing error
- And many other errors → see the IOC Manuals

These errors can then be fixed in the data set. The final data set is called the Quality Controlled Delayed-Mode data set.


# Principles Of Quality Control

- A spike or jump in the data due to instrumental faults



# Principles Of Quality Control


- Missing data (small gaps can be interpolated)





# Principles Of Quality Control

- Reference level changes



# Summary

Sea levels vary on different time scales and for different reasons:

- Tsunamis
- Seiches
- Tides
- Storm surges
- Seasonal cycle
- Mean sea level changes

Tides are dominant, so separation of tidal and non-tidal components is important and facilitates generation of tidal predictions and quality control.